

ITEM	FREQUENCY	WHICHEVER → COMES		ODOMETER READING [NOTE (1)]								REFER TO PAGE
		FIRST ↓	× 1,000 km	1	6	12	18	24	30	36		
		NOTE	× 1,000 mi	0.6	4	8	12	16	20	24		
		NOTE	MONTH		6	12	18	24	30	36		
* FUEL LINE						I		I		I	—	
* THROTTLE OPERATION						I		I		I	163	
AIR CLEANER		NOTE (2)					R			R	146	
CRANKCASE BREATHER		NOTE (3)			C	C	C	C	C	C	152	
SPARK PLUG						R		R		R	160	
* VALVE CLEARANCE								I			—	
ENGINE OIL				R	R	R	R	R	R	R	153	
ENGINE OIL FILTER				R		R		R		R	158	
RADIATOR COOLANT		NOTE (4)				I		I		R	46	
* COOLING SYSTEM						I		I		I	—	
* SECONDARY AIR SUPPLY SYSTEM						I		I		I	—	