

## LEFT HANDLEBAR CONTROLS

### Headlight Switch (1) (Except U)

The headlight switch (1) has three positions: H, P and OFF, marked by a white dot.

H: Headlight, taillight, position light and meter lights on.

P: Position light, taillight and meter lights on.

OFF(dot): Headlight, taillight, position light and meter lights off.

### Headlight Dimmer Switch (2)

Push the dimmer switch to "HI" to select high beam or to "LO" to select low beam.

### Passing Light Control Switch (3)


When this switch is pressed, the headlight flashes on to signal approaching cars or when passing.

### Turn Signal Switch (4)

Move to L to signal a left turn, R to signal a right turn. Press to turn signal off.

### Horn Button (5)

Press the button to sound the horn.



- (1) Headlight switch
- (2) Headlight dimmer switch
- (3) Passing light control switch
- (4) Turn signal switch
- (5) Horn button