



//////////////////////SERIAL NUMBER LOCATION//////////////////////

The frame No. ① is stamped on the left side of the rear wheel axle bracket.
The engine No. ② is located on the left side of the engine at the bottom

These serial numbers are required for applying for warranty claims or ordering parts, the frame No. should be stated to assure receiving the proper parts.



① Frame serial number



② Engine serial number