
Rear Brake Lever

The rear brake lever ① is located on the left handlebar. Application of the rear brake is effected by squeezing the rear brake lever with a force proportional to the braking effort required.

Gear Change Pedal

The gear change pedal ① located near the left foot rest is of the progressive shift, positive stop type, which means one full stroke of the gear change pedal will shift only one gear position.



1 Rear brake lever



1) Gear change pedal