


////////////////////// MAINTENANCE OPERATIONS ////////////////////////


Engine Oil Replenishment

Check engine oil level at pre-riding inspection (refer to page 13) and replenish engine oil when the level is limit mark. Check the level with the oil filler cap dipstick without screwing it in.



Engine Oil Change

As the effectiveness of engine oil is limited to a certain period it is necessary to perform oil changes at suggested intervals shown in the MAINTENANCE SCHEDULE. When draining the oil, it should be performed while the engine is still warm as this will assure complete and rapid draining, saving much time



- ① Oil filler cap dipstick ③ Lower level mark
② Upper level mark