



3. Turn the ignition switch (3) to ON.



(3) Ignition switch

1. With the throttle closed, push the starter button (4). Release the starter button as soon as the engine starts.

Do not use the electric starter for more than 5 seconds at a time. Release the starter button for approximately 10 seconds before pressing it again.



(4) Starter button