
• DK type

Headlight Dimmer Switch (1)

 $\equiv \bigcirc$ - The high beam is on.

| D - The low beam is on.

DK type



- (1) Headlight Dimmer Switch
- (2) Turn Signal Switch
- (3) Horn Button

Turn Signal Switch (2)

Move to "←" to signal a left turn "→" to signal a right turn.

Return to the center (off) when finished.

Horn Button (3)

When the horn button is pressed, the horn will sound.