

MAINTENANCE SCHEDULE

Perform the Pre-ride Inspection (page 30) at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

ITEM		FREQUENCY	WHICHEVER →		ODOMETER READING [NOTE (1)]				Refer to pages
			COMES FIRST ↓	x 1,000 km	1	4	8	12	
		NOTE		MONTH	x 1,000 mi	0.6	2.5	5	
*	FUEL LINE				—	I	I	I	—
*	THROTTLE OPERATION				—	I	I	I	—
**	OIL PUMP AND OIL LINE				—	I	I	I	—
	AIR CLEANER		NOTE 2		—	C	C	C	52-53
	SPARK PLUG				EVERY 1,600 km (1,000 mi) R				54-55
**	DECARBONIZING				EVERY 3,200 km (2,000 mi) C				—
*	CARBURETOR-IDLE SPEED				I	I	I	I	56