

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE(1)]								REFER TO PAGE	
			×1,000km	1	6	12	18	24	30	36		
			×1,000mi	0.6	4	8	12	16	20	24		
		MONTH		6	12	18	24	30	36			
	DRIVE CHAIN	NOTE(4)		I, L, EVERY 1,000km (600mi)								62
	DRIVE CHAIN SLIDER			I	I	I	I	I	I	—		
	BRAKE FLUID	NOTE(5)		I	I	R	I	I	R	12		
	BRAKE PAD WEAR			I	I	I	I	I	I	76		
	BRAKE SYSTEM		I		I		I		I	12, 76		
*	BRAKE LIGHT SWITCH				I		I		I	83		
*	HEADLIGHT AIM				I		I		I	—		
	CLUTCH SYSTEM		I	I	I	I	I	I	I	16		
	SIDE STAND				I		I		I	70		
*	SUSPENSION				I		I		I	69		
*	NUTS, BOLTS, FASTENERS	NOTE(4)	I		I		I		I	—		
**	WHEELS/TYRES	NOTE(4)	I	I	I	I	I	I	I	—		
**	STEERING HEAD BEARINGS		I		I		I		I	—		