

FEATURES

(Not required for operation)

WINDSCREEN HEIGHT ADJUSTMENT

The height of the initial position may be adjusted 60 mm (2.3 in) to a higher or lower position.

To Adjust the Height of an Initial Configuration:

1. Raise the windscreen to the top position (page 50).
2. Remove the windscreen cover by removing screws.

To raise:

Loosen the nuts and slide the windscreen to set lower guide.

To lower:

Loosen the nuts and slide the windscreen to set upper guide.

3. Tighten the nuts and install the windscreen cover after adjustment.
Make sure the windscreen is looked before riding.

