

## DESCRIPTION

### PARTS LOCATION

- (1) Front brake lever
- (2) Throttle lever
- (3) Neutral indicator lamp
- (4) Reverse indicator lamp
- (5) Reverse selector knob
- (6) Rear brake/parking brake lever
- (7) Fuel tank cap
- (8) Fuel valve
- (9) Gearshift pedal
- (10) Recoil starter
- (11) Neutral indicator

