

//////////////////////////////////// CONTENTS //////////////////////////////////////

	Page		Page
TRX SAFETY	1	Carburetor.....	47
DESCRIPTION.....	6	High Altitude	48
Parts Location.....	6	Spark Plug.....	50
Serial Numbers	8	Air Cleaner	51
Parts Function.....	9	Valves	52
Fuel.....	20	Clutch.....	54
Engine Oil.....	22	Brakes.....	55
Tires	24	Throttle Cable.....	59
OPERATION	26	Final Drive Oil.....	60
Pre-ride Inspection	26	Cam Chain.....	61
Starting the Engine	27	Battery	62
Break-in.....	30	Spark Arrestor.....	64
Riding.....	31	STORAGE GUIDE	65
Parking	40	TRANSPORTING.....	67
MAINTENANCE.....	41	SPECIFICATIONS	70
Maintenance Schedule.....	41	WIRING DIAGRAM.....	71
Tool Kit	43	OPTIONAL PARTS	72
Engine Oil.....	44		
Oil Filter Rotor.....	45		
Fuel Filter.....	46		