

MAINTENANCE SCHEDULE

	FREQUENCY	ITEMS	Whichever comes first ⇒	INITIAL		REGULAR		Refer to page		
				mi	100	MAINTENANCE INTERVAL				
						600	1200			
						km	150		1000	2000
NOTE	HOURS	20	100	200						
EMISSION RELATED ITEMS	*	FUEL LINE					I	—		
	*	THROTTLE OPERATION					I	86		
	*	CARBURETOR CHOKE					I	91		
		AIR CLEANER	(NOTE 1)				C	C	87–89	
		AIR CLEANER HOUSING DRAIN TUBE	(NOTE 2)				I	I	90	
		SPARK PLUG					I	I	99	
	*	VALVE CLEARANCE					I	I	I	100
		ENGINE OIL					R	R	R	25,94–97
	**	ENGINE OIL STRAINER SCREEN						C	—	
	**	ENGINE OIL CENTRIFUGAL FILTER						C	—	
	*	ENGINE IDLE SPEED					I	I	I	92

I: Inspect and Clean, Adjust,
Lubricate or Replace if necessary.

C: Clean R: Replace

A: Adjust L: Lubricate