

## MAINTENANCE PRECAUTIONS

Before beginning any maintenance or repairs, read the appropriate instructions and warnings and make sure you have all the tools and materials you will need.

Choose a clean area that is level and has good ventilation and good light. Make sure the engine is off unless otherwise instructed. If you need to replace any parts, remember to use only new genuine Honda parts or their equivalents.

### **⚠ WARNING**

#### **POTENTIAL HAZARD**

Failure to properly maintain the ATV.

#### **WHAT CAN HAPPEN**

Increases the possibility of an accident or equipment damage.

#### **HOW TO AVOID THE HAZARD**

Always follow the inspection and maintenance procedures and schedules described in this Owner's Manual.

Use only genuine Honda replacement parts or parts of equivalent quality.

### **⚠ WARNING**

#### **POTENTIAL HAZARD**

Performing maintenance operations with the engine running.

#### **WHAT CAN HAPPEN**

Increases the chances of injury from moving parts or hot surfaces.

#### **HOW TO AVOID THE HAZARD**

Unless otherwise stated, always turn the engine off before performing any maintenance operations.