

Specifications.....	132
Stalling on a hill	65
Starter button	16
Storage compartment.....	28
Storing procedures	129

T

Throttle	
Cable	86
Lever.....	17, 86
Tires	
Inflation and air pressure	116
Repairing.....	119
Specifications	117
Tread condition	118
Tool kit	81
Transporting procedures.....	124
Turning	
On level ground	60
On slopes	73

V

Valve clearance	101
-----------------------	-----

W

Warning labels	7
Warranty service.....	137
Water	
Draining from brakes	114
Riding through.....	75
Weight limits	35
Wheel removal.....	115
Wiring diagram	134