


## Owner's Manual Compartment

This owner's manual should be stored in the compartment under the rear fender.

When washing your **FOUR TRAX** or riding through water, be careful not to flood this area with water.

### NOTE:

- \* The air pressure gauge should be stored in this owner's manual compartment.



(1) Owner's manual compartment

## Steering Lock

The steering lock (1) is under the left handlebar. To lock the steering, turn the handlebars all the way to the right. Insert the key into the steering lock and turn the key all the way to the left.

### WARNING

- \* *Do not operate the steering lock while riding the **FOUR TRAX**.*



(1) Steering lock  
(2) Ignition key