ł .	nspect and Clean, Adjust, Lubricate or Replace, f necessary Clean R: Replace Adjust L: Lubricate		INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
	FINAL DRIVE OIL		I: (EVERY YEAR) R: (EVERY 2 YEARS)		62
	BRAKE FLUID (FRONT)			I *R: (EVERY 2 YEARS)	58
*	BRAKE SHOES NOT		I: (EVERY YEAR)		56
	BRAKE SYSTEM		I	I	56
*	CLUTCH SYSTEM		I	I	55
*	SUSPENSION			1, L	_
*	SPARK ARRESTER	NOTE (3)		С	63
*	REVERSE LOCK SYSTEM		I	I	_
*	NUT, BOLT, FASTENER		I	I	_
**	WHEEL		I	I	25
**	STEERING HEAD BEARINGS		I: (EVERY YEAR)		
**	STEERING SYSTEM		I: (EVERY YEAR)		_

NOTE: (1) Service more frequently when riding in dusty areas, sand or snow.
(2) Service more frequently after riding in very wet or muddy conditions.
(3) USA only.