

Quick Reference

Scheduled Maintenance	Initial: 100 miles (150 km) Regular: every 600 miles (1,000 km)
Pre-ride Inspection	Check the following items each time before you ride (page 33): engine oil, fuel, tires, nuts & bolts, spark plug & cap, underbody & exhaust system, air cleaner housing drain tube, leaks, loose parts, cargo, cables, throttle, brakes, switches, steering.
Fuel/Capacity	unleaded gasoline, pump octane number 86 or higher 2.40 US gal (9.1 ℓ) reserve: 0.63 US gal (2.4 ℓ)
Engine Oil	API Service Classification SG or higher except oils labeled as energy conserving on the circular API service label, SAE 10W-40, JASO T 903 standard MA, Pro Honda GN4 or HP4 (without molybdenum additives) 4-stroke oil or equivalent
Maximum Weight Capacity	386 lbs (175 kg) rider, all cargo and accessories