LIGHTS

Headlight and Dimmer Switches

The headlight and dimmer switches (Fig. 2-13) are above the engine stop switch, next to the left handgrip.

Turning the headlight switch (1) ♣ (ON) turns the headlight on. Use the dimmer switch (2) to select either high beam ≛D (HI) or low beam ≛D (LO).




Fig. 2-13 (1) Head

(1) Headlight switch

(2) Dimmer switch