

Climbing hills .....	69
Clutch adjustment .....	107
Crossing slopes .....	78
<b>D</b>	
Dimmer switch .....	21
Dipstick .....	30, 100
<b>E</b>	
Engine	
Idle speed adjustment .....	97
Break-in procedures .....	ii
Flooded engine .....	62
Starting the engine .....	59
Engine oil	
Changing oil .....	100
Checking oil level and adding oil .....	100
Oil filler cap/dipstick .....	30, 100
Oil high temperature indicator lamp .....	21
Recommendations .....	101
Engine stop switch .....	15
Exhaust system	
Cleaning .....	38
Purging .....	130
<b>F</b>	
Final gear case oil .....	104
Flag pole bracket .....	32
Flooded engine .....	62
Fuel	
Fuel recommendations .....	90
Fuel fill cap .....	28, 88
Fuel tank capacity .....	88
Fuel valve .....	29
High altitude fuel mixture adjustment .....	99
Refueling .....	88
Reserve fuel supply .....	29
Fuse	
Location .....	111
Replacement .....	112