

## MAINTENANCE SCHEDULE

	FREQUENCY	ITEMS	Whichever comes first ↷	INITIAL	REGULAR		Refer to page
				MAINTENANCE	MAINTENANCE INTERVAL		
				mi	600	1200	
				km	1000	2000	
NOTE	HOURS	20	100	200			
EMISSION RELATED ITEMS	*	FUEL LINE				I	—
	*	THROTTLE OPERATION				I	88
	*	CARBURETOR CHOKE				I	93
		AIR CLEANER	(NOTE 1)		C	C	89—91
		AIR CLEANER HOUSING DRAIN TUBE	(NOTE 2)		I	I	92
		SPARK PLUG			I	I	101
	*	VALVE CLEARANCE			I	I	102
		ENGINE OIL			R	R	27,96—99
	**	ENGINE OIL STRAINER SCREEN				C	—
	**	ENGINE OIL CENTRIFUGAL FILTER				C	—
*	ENGINE IDLE SPEED			I	I	I	94

- I: Inspect and Clean, Adjust,  
Lubricate or Replace if necessary.  
C: Clean      R: Replace  
A: Adjust      L: Lubricate