

Skidding.....	64
Spark arrester.....	126
Spark knock.....	86
Spark plug.....	101
Specifications.....	136
Stalling on a hill.....	67
Starter button.....	16
Storage compartment.....	30
Storing procedures.....	133

T

Throttle	
Cable.....	88
Lever.....	19, 88
Tires	
Inflation and air pressure.....	120
Repairing.....	123
Specifications.....	121
Tread condition.....	122
Tool kit.....	83
Trailer towing	
Operational guidelines.....	38
Weight limits.....	37
Transporting procedures.....	128
Turning	
On level ground.....	62
On slopes.....	75

V

Valve clearance.....	102
----------------------	-----

W

Warning labels.....	7
Warranty service.....	141
Water	
Draining from brakes.....	118
Riding through.....	77
Weight limits.....	37
Wheel removal.....	119
Wiring diagram.....	138