

CONTENTS

| | Page | | Page |
|---|------|------------------------------------|------|
| FOURTRAX SAFETY | 1 | Tool Kit | 49 |
| Safe Riding Rules | 4 | Fuel Filter Screen | 50 |
| Protective Apparel | 4 | Throttle Operation | 51 |
| Modifications | 4 | Air Cleaner | 52 |
| Post-Ride Cleaning and Inspection | 5 | Air Cleaner Case Drain Tube | 53 |
| Loading and Accessories | 5 | Spark Plug | 54 |
| DESCRIPTION | 7 | Valves | 55 |
| Parts Location | 7 | Engine Oil and Filter | 57 |
| Serial Numbers | 9 | Carburetor Choke | 58 |
| Parts Function | 10 | Carburetor | 59 |
| Fuel | 21 | High Altitude | 60 |
| Engine Oil | 24 | Gear Case Oil | 62 |
| Tires | 26 | Brakes | 63 |
| Battery | 28 | Clutch | 68 |
| OPERATION | 29 | Reverse Engagement Lever | 69 |
| Pre-Ride Inspection | 29 | Engine Guard and Skid Plates | 69 |
| Starting the Engine | 30 | Spark Arrester (USA only) | 70 |
| Break-in | 34 | Driveshaft Boots | 71 |
| Riding | 35 | STORAGE GUIDE | 72 |
| Parking | 46 | TRANSPORTING | 74 |
| MAINTENANCE | 47 | SPECIFICATIONS | 77 |
| Maintenance Schedule | 47 | WIRING DIAGRAM | 78 |
| Maintenance Precautions | 49 | | |