

Fuel valve.....	26
High altitude fuel mixture adjustment .....	99
Refueling.....	86
Reserve fuel supply.....	27
Fuses	
Location .....	113
Replacement.....	114

## G

Gasoline (see Fuel)	
Gearshift pedal.....	23
Gearshifting.....	23, 61
Gearcase oil	
Rear final gear case oil.....	105

## H

Headlight switches.....	20
Helmet holder.....	29
High altitude fuel mixture adjustment .....	99
Hills	
Riding across slopes .....	76
Riding down hills.....	74
Riding up hills.....	67
Stopping on hills .....	69
Turning on slopes.....	77

## I

Idle speed adjustment .....	98
Ignition switch.....	13
Indicator lamp	
Reverse indicator lamp .....	22
Neutral indicator lamp .....	22
Inspection, pre-ride.....	36

## K

Kick starter.....	17
-------------------	----

## L

Loading	
Loading guidelines and procedures.....	40