

Maintenance Schedule

ITEMS	FREQUENCY	WHICHEVER COMES FIRST ⇔ NOTE	INITIAL	REGULAR		Refer to page
			MAINT.	MAINT. INTERVAL		
			150	1000	2000	
			km	600	1200	
100	mi	200				
20	HOURS	100	200			
	DRIVESHAFT BOOTS					154
	REAR FINAL GEAR CASE OIL AND DIFFERENTIAL OIL			R. (EVERY 2 YEARS)		113, 115
*	BRAKE FLUID	NOTE 3				132
*	BRAKE SHOE WEAR	NOTE 1				143
	BRAKE SYSTEM					132
*	REVERSE LOCK SYSTEM					126
	SKID PLATES, ENGINE GUARD					152
*	CLUTCH SYSTEM					125
*	SUSPENSION					—
*	SPARK ARRESTER			C	C	153
*	NUTS, BOLTS, FASTENERS					—
**	WHEELS/TYRES					145
**	STEERING SHAFT HOLDER BEARINGS					—
**	STEERING SYSTEM					—

* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Shop Manual.

** In the interest of safety, we recommend these items be serviced only by your Honda dealer.