

# If Your Engine Quits or Won't Start

<b>SYMPTOM: Starter motor doesn't operate.</b>	
<b>POSSIBLE CAUSE</b>	<b>WHAT TO DO</b>
ignition switch OFF	Turn the ignition switch ON.
engine stop switch OFF	Turn the engine stop switch to RUN.
transmission not in neutral	Shift into neutral.
blown fuse	Replace with a new fuse of the same rating (page 185 ).
battery lead loose	Tighten the battery lead. Charge the battery (page 159). If charging doesn't help, see your Honda dealer.
faulty starter motor	If all possible causes are negative, the starter motor may be faulty. See your Honda dealer.

<b>SYMPTOM: Starter motor works, but the engine won't start.</b>	
<b>POSSIBLE CAUSE</b>	<b>WHAT TO DO</b>
out of fuel	Fill the fuel tank.
flooded engine	See <i>Flooded Engine</i> (page 61 ).
loose or unconnected spark plug cap	Install the spark plug cap securely. If the engine still won't start, see your Honda dealer.
loose battery cables	Tighten the battery terminal bolts.
weak battery	Charge the battery (page 159 ). If charging doesn't help, see your Honda dealer.