

CONTENTS

	Page
MAINTENANCE AND REPAIRS	95
Emission Requirements	95
Maintenance Schedule	96
Maintenance Precautions	98
Tool Kit	99
Fuel System	100
Lubrication	112
Engine	118
Clutch	120
Electrical System	122
Brakes	129
Wheels and Tires	139
Seat Removal	144
Engine Guard and Skid Plates	145
Spark Arrester	146
TRANSPORTING YOUR FOURTRAX	148
CLEANING YOUR FOURTRAX	151
STORING YOUR FOURTRAX	153
SPECIFICATIONS	156
WIRING DIAGRAM	158
CONSUMER INFORMATION	159
WARRANTY SERVICE	161
SERIAL NUMBERS AND COLOR LABEL	162
INDEX	163
AUTHORIZED MANUALS	169