

Tires

The recommended “cold” tire pressures are:

(TRX350TE)

		FRONT	REAR
NO CARGO	RECOMMENDED PRESSURE	2.8 psi (20 kPa , 0.20 kgf/cm ²)	2.8 psi (20 kPa , 0.20 kgf/cm ²)
	MAXIMUM PRESSURE	3.2 psi (23 kPa , 0.23 kgf/cm ²)	3.2 psi (23 kPa , 0.23 kgf/cm ²)
	MINIMUM PRESSURE	2.4 psi (17 kPa , 0.17 kgf/cm ²)	2.4 psi (17 kPa , 0.17 kgf/cm ²)
WITH CARGO	RECOMMENDED PRESSURE	2.8 psi (20 kPa , 0.20 kgf/cm ²)	2.8 psi (20 kPa , 0.20 kgf/cm ²)

(TRX350FE)

		FRONT	REAR
NO CARGO	RECOMMENDED PRESSURE	3.6 psi (25 kPa , 0.25 kgf/cm ²)	3.6 psi (25 kPa , 0.25 kgf/cm ²)
	MAXIMUM PRESSURE	4.0 psi (28 kPa , 0.28 kgf/cm ²)	4.0 psi (28 kPa , 0.28 kgf/cm ²)
	MINIMUM PRESSURE	3.2 psi (22 kPa , 0.22 kgf/cm ²)	3.2 psi (22 kPa , 0.22 kgf/cm ²)
WITH CARGO	RECOMMENDED PRESSURE	3.6 psi (25 kPa , 0.25 kgf/cm ²)	3.6 psi (25 kPa , 0.25 kgf/cm ²)