

## MAINTENANCE SCHEDULE

	FREQUENCY ITEMS	Whichever comes first ⇒	INITIAL	REGULAR		Refer to page	
			MAINTENANCE	MAINTENANCE INTERVAL			
			mi	600	1200		
			km	1000	2000		
NOTE	HOURS	20	100	200			
EMISSION RELATED ITEMS	* FUEL LINE				I	—	
	* THROTTLE OPERATION				I	98	
	* CARBURETOR CHOKE				I	103	
	AIR CLEANER	(NOTE 1)			C	C	99—101
	AIR CLEANER HOUSING DRAIN TUBE	(NOTE 2)			I	I	102
	SPARK PLUG				I	I	112—113
	* VALVE CLEARANCE			I	I	I	113
	ENGINE OIL			R	R	R	35, 106—110
	ENGINE OIL FILTER			R	R	R	108—110
	* ENGINE IDLE SPEED			I	I	I	104

I: Inspect and Clean, Adjust,  
Lubricate or Replace if necessary.

C: Clean R: Replace

A: Adjust L: Lubricate