

Maintenance Schedule

ITEMS		FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
			⇒	mi	100	600	1200	
				km	150	1000	2000	
			NOTE	HOURS	20	100	200	
NON EMISSION RELATED ITEMS		DRIVESHAFT BOOTS (TRX350FM only)						152
		REAR FINAL GEAR CASE OIL AND DIFFERENTIAL OIL (TRX350FM only)				(R:EVERY 2 YEARS)		110-113
	*	BRAKE FLUID	NOTE 3					130
	*	BRAKE SHOE WEAR	NOTE 1					141
		BRAKE SYSTEM						130
	*	REVERSE LOCK SYSTEM						123
		SKID PLATES, ENGINE GUARD						151
	*	CLUTCH SYSTEM						122
	*	SUSPENSION						--
	*	SPARK ARRESTER				C	C	129
	*	NUTS, BOLTS, FASTENERS						--
	**	WHEELS/TIRES						--
	**	STEERING SHAFT HOLDER BEARINGS						--
**	STEERING SYSTEM						--	

- * Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 206).
- ** In the interest of safety, we recommend these items be serviced only by your Honda dealer.