

MAINTENANCE SCHEDULE

	FREQUENCY	ITEMS	Whichever comes first ↘	INITIAL MAINTENANCE		REGULAR MAINTENANCE INTERVAL		Refer to page		
				mi	100	600	1200			
				km	150	1000	2000			
				NOTE	HOURS	20	100		200	
EMISSION RELATED ITEMS	*	FUEL LINE					I	—		
	*	THROTTLE OPERATION					I	86		
		AIR CLEANER	(NOTE 1)				C	C	87–89	
		AIR CLEANER HOUSING DRAIN TUBE	(NOTE 2)				I	I	90	
		SPARK PLUG					I	I	105	
	*	VALVE CLEARANCE					I	I	106	
		ENGINE OIL					R	R	R	24,94–96
		ENGINE OIL FILTER					R	R	R	97–100
	*	ENGINE OIL STRAINER SCREEN IN OIL TANK							C	—
	*	ENGINE IDLE SPEED					I	I	I	91

I: Inspect and Clean, Adjust,
Lubricate or Replace if necessary.

C: Clean R: Replace

A: Adjust L: Lubricate