

# Is Your ATV Ready to Ride?

---

Check these items after you get on the ATV:

- |  |   |
|--|---|
| <i>Throttle</i>                              | Check the freeplay and adjust if needed. Press the throttle to make sure it moves smoothly without sticking, and snaps shut automatically when it is released, in all steering positions (page 102 ). |
| <i>Brakes</i>                                | Squeeze the front brake lever and step on the rear brake pedal to check that the controls operate normally. Check for proper freeplay. Make sure there is no brake fluid leakage (page 122 ).         |
| <i>Clutch Lever</i>                          | Check for smooth operation and adjust if needed (page 104).   |
| <i>Headlight and Headlight Dimmer Switch</i> | Check for proper function (page 19 ).   |
| <i>Engine Stop Switch</i>                    | Check for proper function (page 18 ).   |
| <i>Steering</i>                              | Check that the wheels turn properly as you steer the handlebar.   |

Remember, be sure to take care of any problem you find, or have your Honda dealer correct it before you ride.