# **Spark Plug**

## **Spark Plug Recommendation**

standard spark plug	DPR8Z (NGK) or
	X24GPR-U (DENSO)
for extended high	DPR9Z (NGK) or
speed riding	X27GPR-U (DENSO)

Use only the recommended type of spark plug in the recommended heat range.


### NOTICE

Using spark plugs with an improper heat range can cause engine damage.

#### **Spark Plug Replacement & Inspection**

Refer to Safety Precautions on page 75.

- 1. Clean any dirt from around the spark plug base.
- 2. Disconnect the spark plug cap (1). Take care to avoid damaging the spark plug wire when disconnecting the cap.
- 3. Using the spark plug wrench provided in the tool kit, remove the spark plug.



(1) spark plug cap

#### 110 Servicing Your Honda