

6. Wash the air cleaner in nonflammable or high flash point solvent and allow it to dry thoroughly.

## **WARNING**

### **POTENTIAL HAZARD**

Using gasoline or low flash point solvents for cleaning ATV parts.

### **WHAT CAN HAPPEN**

A fire or explosion could result.

### **HOW TO AVOID THE HAZARD**

Use only a nonflammable or high flash point solvent to clean ATV parts.

7. Soak the air cleaner in Pro Honda Foam Filter Oil or an equivalent [Canadian Vehicles: gear oil (SAE 80–90)] until saturated, then squeeze out the excess oil.

### **CAUTION:**

**Twisting the air cleaner when squeezing out excess oil could damage the air cleaner.**

8. Reassemble by reversing the disassembly sequence.