VEHICLE PREPARATION

Pre-Ride Inspection

Inspect your FOURTRAX every day before you ride it. Checking the items below will take only a few minutes, and in the long run, they can save time, expense, and possibly your life.

- 1. **Engine oil level.** Check the oil level and add oil if required (pages 100 104). Check for leaks.
- 2. Fuel level. Fill the fuel tank when necessary (pages 88-91). Check for leaks.
- Brakes. Check operation. Make sure there is no brake fluid leakage. If necessary, adjust free play (pages 119 – 128).
- 4. **Tyres.** Check condition and pressure (pages 130 132).
- 5. **Throttle.** Check for smooth opening and closing in all steering positions.
- Headlight and headlight dimmer switches. Check for proper function (page 21).
- 7. Engine stop switch. Check for proper function (page 15).
- 8. Driveshaft boots. Check for damage (page 138).
- Nuts, bolts, fasteners. Check the wheels to see that the axle nuts are tightened. Check the security of all other nuts, bolts and fasteners.
- Steering. Check that the wheels turn properly as you steer the handlebars.
- 11. Cargo. Check that all cargo is properly secured.
- 12. **Underbody and exhaust system**. Check for, and remove, any dirt, vegetation or other debris that could be a fire hazard or interfere with the proper operation of the vehicle.
- Air cleaner housing drain tube. Check for deposits in the drain tube. If necessary, clean the tube (page 96) and check the air cleaner case.