

Indicators & Displays

7	Mode button	Selects display in the lower parts of multi-function display (page 28). This button also used to change the speed and mileage unit (page 31), adjusts the clock (page 35) and resets tripmeter, maintenance tripmeter and maintenance hourmeter (page 40).
---	-------------	--