

## F

Final gear case oil .....	117
Flag pole bracket.....	39
Flooded engine .....	70
Fuel	
Fuel fill cap.....	35, 100
Fuel gauge .....	34
Fuel recommendations .....	102
Fuel tank capacity .....	100
Fuel valve.....	36
High altitude fuel mixture adjustment .....	111
Refueling.....	100
Reserve fuel supply.....	36
Fuses	
Location .....	127
Replacement, main fuse .....	127
Replacement, main fuse (Electric shift motor).....	128
Replacement, sub fuses .....	129

## G

Gear change tool.....	74, 99
Gasoline (see Fuel)	
Gearshift switch	
Downshift switch .....	31, 71
Upshift switch.....	31, 71
Gearshifting.....	31, 71
Gearcase oil	
Rear final gear case oil.....	117
Gear position indicator .....	27

## H

Headlight switches.....	21
Helmet holder.....	38
High altitude fuel mixture adjustment .....	111
Hills	
Riding across slopes .....	90
Riding down hills.....	88
Riding up hills .....	81
Stopping on hills .....	83
Turning on slopes.....	91
Hourmeter .....	29