

I	
Idle speed adjustment	110
Ignition switch	14
Indicator	
Gear position indicator	27
Neutral indicator	22
Oil high temperature indicator	22
Reverse indicator	22
Inspection, pre-ride	46
L	
Loading	
Loading guidelines and procedures	50
Weight limits	49
Lubrication	
(see Engine oil, Gear case oil and differential oil)	
M	
Maintenance	
Precautions	98
Schedule	96
Modifications	54
Multi-function display	24
N	
Neutral indicator	22
Noise emission control system	163
O	
Obstacles, riding over	92
Odometer	28
Oil (see Engine oil, Gear case oil and differential oil)	
Oil filler cap/dipstick	37, 112
Oil filter, changing	114
Oil high temperature indicator	22
Owner's manual compartment	41