

## Indicators & Display

---

6	Odometer/tripmeter select button	Selects display of the odometer or tripmeter. Resets the tripmeter to zero (0) (page 19).
7	Hourmeter/digital clock select button	Selects display of the hourmeter or digital clock (pages 20 , 21 ).
8	Hour select button	Advances the hour displayed by the digital clock (page 21 ).
9	Minute select button	Advances the minutes displayed by the digital clock (page 21 ).