

Maintenance Schedule

Maintenance Procedures:

I: inspect and clean, adjust, lubricate, or replace, if necessary

C: clean

A: adjust

L: lubricate

R: replace

ITEMS	FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
		↔	km	150	1000	2000	
			mi	100	600	1200	
		NOTE	HOURS	20	100	200	
*	FUEL LINE					I	—
*	THROTTLE OPERATION					I	137
*	CARBURETOR CHOKE					I	139
	AIR CLEANER	NOTE 1				C	131
	AIR CLEANER HOUSING DRAIN TUBE	NOTE 2				I	136
	SPARK PLUG					I	141
*	VALVE CLEARANCE			I	I	I	144
	ENGINE OIL			R	R	R	114
	ENGINE OIL FILTER			R	R	R	119
*	ENGINE IDLE SPEED			I	I	I	140
	RADIATOR COOLANT	NOTE 3				I	127
*	COOLING SYSTEM	NOTE 2				I	—

* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Shop Manual.