

# System Start-up

---

5. Reconnect the negative (—) terminal lead and install in the reverse order of removal.
  - If you can not obtain a position fix after performing this procedure, see your Honda dealer.