

Maintenance Schedule

Maintenance Procedures:

I: inspect and clean, adjust, lubricate, or replace, if necessary

C: clean

A: adjust

L: lubricate

R: replace

ITEMS	FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page	
		⇔	mi	100	600	1200		
			km	150	1000	2000		
		NOTE	HOURS	20	100	200		
*	FUEL LINE					I	—	
*	THROTTLE OPERATION					I	169	
*	CARBURETOR CHOKE					I	171	
	AIR CLEANER	NOTE 1				C	C	163
	AIR CLEANER HOUSING DRAIN TUBE	NOTE 2				I	I	168
	SPARK PLUG					I		173
*	VALVE CLEARANCE			I	I	I		176
	ENGINE OIL			R	R	R		146
	ENGINE OIL FILTER			R	R	R		151
*	ENGINE IDLE SPEED			I	I	I		172
	RADIATOR COOLANT	NOTE 3				I	I	159
*	COOLING SYSTEM	NOTE 2				I	I	—

* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 260).