


## **Controls & Features**

## **Parking Brake**



(2) rear brake lever/parking brake lever

The lock lever (1) on the rear brake lever/parking brake lever (2) allows it to be used as a parking brake. To operate, first squeeze the rear brake lever/parking brake lever using your left hand and then lock it with the lock lever using your right hand. See *Parking* page 141.

The brakelights are activated by applying the parking brake. When using the parking brake, be sure to turn the ignition switch OFF ( ) to avoid discharging the battery.