





## Indicators & Displays

The indicators and displays on your ATV keep you informed, alert you to possible problems, and make your riding safer and more enjoyable. Refer to the indicators frequently. Their functions are described on the following pages.

TRX500FE



TRX500FPE



- |   |  |
|---|--|
| (1) RESET button                        | (7) multi-function display   |
| (2) odometer/tripmeter<br>select button | (8) hour select button   |
| (3) 4WD indicator                       | (9) minute select button   |
| (4) high oil temperature indicator      | (10) adjust button   |
| (5) neutral indicator                   | (11) PS (Electric Power<br>Steering) indicator<br>(TRX500FPE only) |
| (6) reverse indicator                   |  |

USA: Displays read in mph and miles.  
Canada: Displays read in km/h and kilometers.

