

# Indicators & Displays


## Fuel Gauge

The fuel gauge liquid crystal display (1) shows the approximate fuel supply available. The fuel tank capacity is:

17.0 ℓ (4.49 US gal , 3.74 Imp gal)

When segment RES (2) flashes, you should refill the tank as soon as possible. The amount of fuel remaining when the flashing starts is approximately:

4.1 ℓ (1.08 US gal , 0.90 Imp gal)



(1) fuel gauge

(2) segment RES

All segments will flash, when the fuel gauge function is fail. See your Honda dealer.

