

Maintenance Schedule

ITEMS	FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
		↔	km	150	1000	2000	
			mi	100	600	1200	
		NOTE	HOURS	20	100	200	
DRIVE SHAFT BOOTS							164
REAR FINAL GEAR							120
CASE OIL AND DIFFERENTIAL OIL					(RE:EVERY 2 YEARS)		122
* BRAKE FLUID	NOTE 3						145
* BRAKE SHOES WEAR	NOTE 1						148
* BRAKE PADS WEAR	NOTE 1,2						154
BRAKE SYSTEM							145
SKID PLATE, ENGINE GUARD							163
* SUSPENSION							—
* SPARK ARRESTER					C	C	143
* NUTS, BOLTS, FASTENERS							—
** WHEELS/TYRES							156
** STEERING SHAFT HOLDER BEARINGS							—
** STEERING SYSTEM							—

- * Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Shop Manual.
- ** In the interest of safety, we recommend these items be serviced only by your Honda dealer.