

Indicators & Controls

This section shows the location of all indicators and controls you would normally use before or while riding your ATV.

The items listed on this page are described in this section. Instructions for other components are presented in other sections of this manual where they will be most useful.

Operation Component Locations	14
Indicators.....	17
Controls & Features	20
Fuel Valve	20
Ignition Switch	21
Start Button	22
Engine Stop Switch.....	22
Headlight Switch.....	23
Headlight Dimmer Switch.....	23
Throttle Lever	24
Clutch Lever/Parking Brake Lever	24
Reverse Assist Lever.....	25
Front Brake Lever	26
Rear Brake Pedal.....	26
Parking Brake.....	27
Flag Pole Bracket.....	28