


## SERIAL NUMBERS

The frame and engine serial numbers are required by your dealer when ordering replacement parts. Record the numbers here for your reference.


FRAME NO. \_\_\_\_\_



(1) Frame serial number

The frame serial number (1) is stamped on the right side of the frame. The engine serial number (2) is stamped on the left side of the crankcase.

ENGINE NO. \_\_\_\_\_



(2) Engine serial number