

TIRES

Although the tires are designed specifically for off-road use, they are not immune to punctures. Always select your riding area with care.

WARNING

* *The TRX is not designed to be driven on paved surfaces. Handling and control will be severely affected.*

Check tire pressure frequently with the air pressure gauge supplied with this TRX.

Tires should be inflated to the recommended pressure.

NOTE:

- * Tire pressure should be checked when the tires are “cold,” before you ride.
- * Check the tire pressure before you ride.

	Front	Rear
TIRE SIZE	16x8.00-7	16x8.00-7
TIRE BRAND	OHTSU	OHTSU
Recommended pressure	2.2 psi (15 kPa, 0.15 kg/cm ²)	2.2 psi (15 kPa, 0.15 kg/cm ²)
Max. pressure	2.6 psi (18 kPa, 0.18 kg/cm ²)	2.6 psi (18 kPa, 0.18 kg/cm ²)
Min. pressure	1.8 psi (12 kPa, 0.12 kg/cm ²)	1.8 psi (12 kPa, 0.12 kg/cm ²)

WARNING

- * *Maintain proper tire air pressure. Improperly inflated tires may adversely affect maneuverability and may cause loss of control.*
- * *When replacing tires use only the size, type and brand identified in the chart. The use of different sizes or types of tire can severely effect vehicle handling.*