

T

| | |
|----------------------------------|---------|
| Throttle | |
| Cable | 120 |
| Lever..... | 28, 120 |
| Limiter, adjustment | 82 |
| Limiter, removal | 83 |
| Tires | |
| Inflation and air pressure | 149 |
| Pressure gauge..... | 44 |
| Repairing..... | 152 |
| Specifications | 150 |
| Tread condition | 151 |
| Tool kit | 115 |
| Transporting procedures..... | 156 |
| Turning | |
| On level ground..... | 94 |
| On slopes | 106 |

V

| | |
|-----------------------|-----|
| Valve clearance | 137 |
|-----------------------|-----|

W

| | |
|----------------------------|-----|
| Warning labels | 13 |
| Warranty service..... | 168 |
| Water | |
| Draining from brakes | 146 |
| Riding through..... | 109 |
| Weight limits | 64 |
| Wheel removal..... | 148 |
| Wiring diagram | 165 |